Yongwon KIM **Presentation** Case Similarity: 0.0 **PASS** 

인공지능 발표

Let's Safe!

# 안전하세요!

산업현장 안전을 위한 안전모 탐지 시스템 구현

제주대학교 컴퓨터공학전공

2022208020 김용원 인공지능 발표

CONTENTS



Yongwon KIM ORIETATION

#### **MIRI COMPANY**


### 목차

#### **CONTENTS**

- 1. 개요, 필요성
- 2. 관련 연구/내용
- 3. 내용 요약
- 4. 캐글
- 5. 코드 설명
- 6. 결론
- 7. 질의응답

개요/필요성

**INTRODUCTION** 



TF Keras openCV

#### 개요

AI 기술을 이용한 안전모 감지 서비스 진행하여 새로운 시대에 맞춘 진보한 시스템 구축, 더 정확하고 더 빠른 서비스 제공

이제는 안전입니다!

#### 개요/필요성

#### INTRODUCTION

#### 국민일보

#### 건설현장 33% 안전모도 안 썼다... 지난해 236명 추락 사망

[벼랑 끝 노동자 안전] ③ 추락위험 일제정검 <끝>

일찍 2021-07-20 04:04






사진=개타이미지

전국 건설현장 3곳 중 1곳은 안전모 미착용 등 개인 보호구를 제대로 갖추지 않고 있다는 정부 조사 결과가 나왔다. 안전난간·작업 발판을 설치하지 않은 공사장도 상당수였다. 노동자 생명을 보호하는 최소한의 안전 체계마저 정상 작동하지 않고 있다는 지적이다. 이에 고용노동부와 한국산업안전보건공단은 이달부터 산업재해 현장점검을 정례화해 '안전한 일터' 조성에 본격 나서기로 했다.



#### 필요성



2020년 산업재해 사망자 882명 중 건설업 사망자 수 (51.9%) -고용노동부-



458명

관련 연구/내용

**RESEARCH** 



# 관련 현황

LG

#### "안전모 미착용자 실시간 감지"...스마트팩토리 사업 뛰어든 LGU+

윤정민 기자 | 입력 2023. 3. 12. 09:00

00

♥ (A) (B) (B) (B)

#### 기사내용 요약

LGU+, 2023 스마트공장·자동화산업전서 '스마트팩토리' 선보여 중대재해처벌법 시행 후 지능형 보안 솔루션 문의 250% 늘어



[서울=뉴시스] 윤정민 기자 = 지난 9일 서울 코엑스에서 열린 '2023 스마트공장·자동화산업전'에서 LG유플러스가 선보인 디지털트윈 기반 통합관제센터 솔루션. 한 근로자가 안전모를 착용하지 않은 모습이 폐쇄회로(CC)TV 에 찍히자 통하관제센터에 악립이 유리고 있다. 2023 03 09. alpaca@newsis.com \*재판매 및 DB 규지

SK SHILDERS

#### SK쉴더스, SK텔레콤-SK플래닛과 ICT기반 산업안전장치 출시

발행일: 2022-03-08 10:36 지면: 2022-03-09 🚨 12면







SK쉴더스가 명상통합관제기술과 SK텔레콤 무선통신기술·SK플래닛 센싱기술을 융합한 정보통신기술(ICT)기반 이동형 산업안전장치를 출시했다. 관련 연구/내용

**RESEARCH** 



### 관련 현황

HYUNDAI


**ELEVATOR** 

#### '안전모 미착용자 감지' 알람..AI로 현장 안전 관리

A 한민형 기자 | ② 입력 2022.12.05 15:47 | 即댓글 0



현대건설, 현장 CCTV 영상 분석 시스템 자체 개발 AI 영상 분석 활용해 건설 현장 안전·품질 관리 레미콘 품질 실시간 모니터링 시스템도 개발



\* 현대건설이 현장 CCTV 영상 분석 시스템 안전 위반사항 탐지 및 알람을 제공한다

AI(인공지능)기술이 건설 현장의 안전관리에 도입, 현장의 안전사고가 감소할 것으로 보인다. 현대건설은 AI(인공지능) 기반의 건설 현장 영상 분석 기술을 개발하고 특허를 등록하는 등 스 마트 건설 관리에 속도를 내고 있다고 5일 밝혔다. SAMSUNG S-1

경제: 경제일반

#### 안전모 벗자 엥~ 경고음…사고 줄이는 똑똑한 CCTV

중앙일보 | 입력 2023.08.04 00:01

지면보기 ①

박해리 기자 구독



지난 1일 서울 에스핀 R&D센터에서 본지 기자가 SVMS 를 제험하고 있다. 안전모를 벗으니 CCTV가 이를 안식해 경고름이 옮겼다. [사진 에스마

서울 중구 순화동 에스윈 사옥에 있는 연구개발(R&D)센터, 지난 1일 찾은 이곳에서는 지능형 폐쇄회로(CC)TV를 활용해 공장 내 작업자들의 움직임을 분석하는 실험이 진행되고 있었다.

기자는 이날 노란색 작업복과 안전모를 착용하고 안전수칙 테스트에 참여했다. 카메라 앞에 서자 가로 2.5m, 세로 1.5m짜리 대형 화면의 16개 모니터에 기자의 모습이 나타났다. 안전모를 벗자 불과 5초도 안 돼 '엥-' 하고 소란스러운 경고음이 울리고, 화면에는 빨간색 알림 표시가 떴다. 이 알림은 실시간으로 관리자의 스마트폰 애플리케이션(앱)으로 전송됐다. 요약

**SUMMARY** 

#### 안전모 착용 중요

목숨은 소중하니까요



#### 대기업이 진행 중

중대재해처벌법 시행 이후 대기업 도입 늘어 삼성, LG, 현대건설 등



#### It's Possible

대부분의 대기업이 홍보하는 시스템 한계 존재 장비 포함 모든 시스템 판매

별도의 카메라 장비 구매가 필요없다면? It's Possible



# 크게 돈이됩니다-

# 那量 Kaggle



Notebook Input Output Logs Comments (0)

TensorFlow

JOSU - 3Y AGO - 5,561 VIEWS

BBox helmet detector with Tensorflow (>=) 2.3 and Retinanet (SSD with Resnet 50 v1) Object detection model on COCO 2017 dataset

. Suggested Metrics in last cell

import os TF\_FOLDER = 'TF23\_SSD\_RESNET50' WORKSPACE = 'helmet' PROJECT = 'detector' # Bounding Box classes CLASSES = ['helmet', 'head', 'person'] RUN\_DIR = os.getcwd() # Current dir TF\_DIR = RUN\_DIR + "/" + TF\_FOLDER TF\_PROJECT\_DIR = TF\_DIR + "/" + WORKSPACE + "/" + PROJECT MODELS\_DIR = RUN\_DIR + "/" + TF\_FOLDER + "/models" RESEARCH\_DIR = MODELS\_DIR + "/research" # Pre-Trained model from Tensorflow 2 model zoo PRE\_MODEL\_FILE = 'ssd\_resnet50\_v1\_fpn\_640x640\_coco17\_tpu-8.tar.gz' PRE\_MODEL\_URL = 'http://download.tensorflow.org/models/object\_detection/tf2/20200711/ssd\_resnet50\_v1\_fpn\_640x640\_coco17\_tpu-8.tar.g PRE\_MODEL\_TYPE = 'ssd\_resnet50\_v1\_fpn\_640x640\_coco17\_tpu-8' PRE\_MODEL\_CHECKPOINT = PRE\_MODEL\_TYPE + '/checkpoint/ckpt-0' MY\_PRE\_MODEL\_DIR = TF\_PROJECT\_DIR + '/models/ssd\_resnet50\_v1\_fpn' # Kaggle dataset paths DATA\_XML\_DIR = '/kaggle/input/hard-hat-detection/annotations/'

### 캐글

Copy & Edit 155

Version 1 of 2

왠지 모르게 신뢰가 가는 프로필 사진

5500여개의 높은 조회수

155개의 **Copy & Edit** 



### 那量 Kaggle

Requirement already up-to-date: tensorflow in /opt/conda/lib/python3.7/site-packages (2.3.8)
Requirement already satisfied, skipping upgrade: h5pyc2.11.0, =2.10.8 in /opt/conda/lib/python3.7/site-packages (from tensorflow) (2.10.8)
Requirement already satisfied, skipping upgrade: wheel>=0.25 in /opt/conda/lib/python3.7/site-packages (from tensorflow) (0.34.2)
Requirement already satisfied, skipping upgrade: google-pasta>=0.1.8 in /opt/conda/lib/python3.7/site-packages (from tensorflow) (0.2.8)
Requirement already satisfied, skipping upgrade: wrapt>=1.1.1 in /opt/conda/lib/python3.7/site-packages (from tensorflow) (1.11.2)
Requirement already satisfied, skipping upgrade: asturparse==1.6.3 in /opt/conda/lib/python3.7/site-packages (from tensorflow) (1.6.3)

ENDOR: Could not find a version that satisfies the requirement famorboard(3,>>2.5.0 (from tamorflow) (from versions: nume) EAROR: No establing distribution found for teocorboard(2,>>2.5.0 (from teocorflow)

notebook0e649fdead Draft swed

### 안되는데요?

Downloading data from https://github.com/tensorflow/models/archive/master.zip

```
File Edit View Run Help
Explore and run machine learning code with Kaggle Notebooks. Sign in or Register to continue editing.
                                                                                                                                                                                                    ● Draft Session (9m)
 RESEARCH_DIR = MODELS_DIR + "/research"
           # Pre-Trained model from Tensorflow 2 model 200
           PRE_MODEL_FILE = 'ssd_resnet58_v1_fpn_640x640_coco17_tpu-8.tar.gz'
          PRE_MODEL_URL = 'http://download.tensorflow.org/models/object_detection/tf2/20200711/ssd_resnet50_v1_fpn_640x640_coco17_tpu-8.tar.gz'
PRE_MODEL_TYPE = 'ssd_resnet50_v1_fpn_640x640_coco17_tpu-8'
           PRE_MODEL_CHECKPOINT = PRE_MODEL_TYPE + '/checkpoint/ckpt-8'
           MY_PRE_MODEL_DIR = TF_PROJECT_DIR + '/models/ssd_resnet50_v1_fpn'
           # Kaggle dataset paths
           DATA_XML_DIR = '/kaggle/input/hard-hat-detection/annotations/'
          DATA_IMAGES_DIR = '/kapple/input/hard-hat-detection/images/
           CHECKPOINT_EVERY = 1888
           BATCH_SIZE = 4
          # Create project folder and install Tensorflow 2.3
           import pathlib
           import sys
           from os import path
           os.environ['TF_CPP_MIN_LOG_LEVEL'] = '2'
           !mkdir -p STF_FOLDER
           %od STF_FOLDER
           !{sys.executable} -m pip install --upgrade tensorflow
          /kaggle/working/TF23_SSD_RESNETSB
```

```
Traceback (most recent call last)
/opt/conda/lib/python3-7/urllib/request.py in do most(self, http_class, req, **http_conm_args)
1318 h.request(req.get_method(), req.selector, req.data, headers,
    1319
1320
                      encode_chunked-req.has_header('Transfer-encoding'))
except OSError as arr: # timeout error
 /opt/conds/lib/python3.7/http/client.py in request(self, method, url, body, headers, encode_chumked)
1251 ""Send a complete request to the server."""
                  self._send_request(method, url, body, headers, encode_chunked)
 /opt/conda/lib/python3.7/http/client.py in _send_request(self, method, wrl, body, headers, encode_chunked)
                body = encode(body, 'body')
self.endheaders(body, encode_chunked-encode_chunked)
   1298
 /opt/conda/lib/python3.7/http/client.py in andheaders(self, message_body, encode_chunked)
                 self._send_output(message_body, encode_chunked-encode_chunked)
 /opt/conda/lib/python3.7/http/client.py in _cend_nutput(self, message_body, encode_chunked)
                  self send(msg)
 /opt/conde/lib/python3-7/http/client.py in smn(self, data)
 /opt/conde/lib/python3.7/http/client.py in comment(self)
                      super().connect()
    1415
                 /python3.7/mttp/clientipy
self.sock = self_create_connection(
  -> 938 (self.host,self.port), self.timeout, self.source_address)
939 self.sock.setsockopt(socket.IPPROTO_TCP, socket.TCP_NODELAY, 1)
/opt/conda/lib/python3.7/socket.py in create_connection(eddress, timeout, source_address)
786 err = Nohe
--> 787 for rea in getaddrinfo(host, port, #, SOCK_STREAM):
788 af, socktype, proto, canonname, sa = res
 /opt/conda/lib/python3.7/socket.py in getandrinfu(bost, port, family, type, prutp, flags)
    751 addrlist = []
752 for res in _socket.getaddrinfo(host, port, family, type, proto, flags):
753 af, socktype, proto, canonname, sa = res
galerror: [Errno -3] Temporary failure in name resolution
During handling of the above exception, another exception occurred:
 opt/conda/lib/python3-7/site-packages/tensorflow/python/keras/utils/data_utils.py in get_file(feame, origin, untar, md5_hash, file_bash, cache_subdir, hash_algorithm, extract, archive_forunt, cache_dir)
                   urlretrieve(origin, fpath, dl_progress)
/opt/conda/lib/python5.7/urllib/request.py in urinetriese(url, filename, reporthook, data)
  246
3 247 with contextlib.closing(urlopen(url, data)) as fp:
248 headers = fp.info()
 opt/conda/lib/python3.7/urllib/request.py in urlopen(url, date, timeout, cafile, capath, cadefault, contest)
   221 opener - opener

> 222 return opener open(url, data, timeout)


223
 /opt/conda/lib/python3.7/urllib/request.py in open(self, fullur), dots, tiseout)
                 response - self._open(req, data)
```

Back-up

# 대안 발표









발표

It's Mine

### 간단 설명

트레이너



시해기




STEP 2 Visualizer

```
from tensorflow.keras.preprocessing.image import ing_to_array from tensorflow.keras.models import load_model
import numpy as mp
import inutils
import time
import cv2
import matplotlib.pyplot as plt
 def detect_and_predict_hat(frame, faceNet, hatNet):
       tocs = []
```

STEP 1 Trainer


```
Ble Edit View Navigate Code Befactor Ryn Tools Git Window Help 1 - train, must districtivity
  g 🔳 . 🖰 I 🛨 🗢 — 🖟 testpy . 🖟 train_mask_detector.py
                                                     on tensorflow.keras.preprocessing.image import ImageDataSeneratu
E > m 1 (4 番目 (2) CirclenWi
                                                from tensorflow keras layers import AveragePooling2D
from tensorflow keras layers import Dropout
                                                 from tensorflow.keras.layers import Flatten
from tensorflow.keras.layers import Dense
                                                  from tensorflow.keras.utils import to_categorical from sklearn.preprocessing import Label&inarizer
                                                  from sklearn.metrics import classification_report import matpletlib.pyplot as plt
                                                 OIRECTORY = "C:/Users/kysto/besstop/1/Con_detector/sedel"
CATEGORIES = ["buld", "<u>Sefectyhelset</u>"]
```




# More Dataaaaa!














### Trainer

트레이너



실행기



```
om tensorflow.keras.preprocessing.image import ImageDataGenerator
  om tensorflow.keras.applications import MobileNetV2
 rom tensorflow.keras.layers import AveragePooling2D
  om tensorflow.keras.layers import Dropout
  om tensorflow.keras.layers import Flatten
  om tensorflow.keras.layers import Dense
  om tensorflow.keras.layers import Input
  om tensorflow.keras.models import Model
  om tensorflow.keras.optimizers import Adam
  om tensorflow.keras.applications.mobilenet_v2 import preprocess_input
  om tensorflow.keras.preprocessing.image import img_to_array
  om tensorflow.keras.preprocessing.image import load_img
  om tensorflow.keras.utils import to_categorical
  rom sklearn.preprocessing import LabelBinarizer
 rom sklearn.model_selection import train_test_split
  om sklearn.metrics import classification_report
  port matplotlib.pyplot as plt
  port numpy as np
INIT_LR = 1e-4
EPOCHS = 40
BS = 64
DIRECTORY = "C:/Users/kywtr/Desktop/1/Con_detector/model"
CATEGORIES = ["bald", "Safetyhelmet"]
data = []
labels = []
   category in CATEGORIES:
   path = os.path.join(DIRECTORY, category)
   for img in os.listdir(path):
        img_path = os.path.join(path, img)
        image = load_img(img_path, target_size=(224, 224))
        image = img_to_array(image)
        image = preprocess_input(image)
        data.append(image)
        labels.append(category)
```

```
b = LabelBinarizer()
 abels = lb.fit_transform(labels)
labels = to_categorical(labels)
data = np.array(data, dtype="float32")
labels = np.array(labels)
(trainX, testX, trainY, testY) = train_test_split(data, labels, test_size=0.20, stratify=labels, random_state=42)
 aug = ImageDataGenerator(
baseModel = MobileNetV2(weights="imagenet", include_top=False, input_tensor=Input(shape=(224, 224, 3)))
 eadModel = baseModel.output
 eadModel = AveragePooling2D(pool_size=(7, 7))(headModel)
 eadModel = Flatten(name="flatten")(headModel)
 eadModel = Dropout(8.5)(headModel)
 meadModel = Dense(2, motivation="softmax")(headModel)
 model = Model(inputs=baseModel.input, outputs=headModel)
   r layer in baseModel.layers:
   layer.trainable = False
model.compile(loss='binary_crossentropy', optimizer=opt, metrics=['accuracy"])
    aug.flow(trainX, trainY, batch_size=BS),
    validation_steps=len(testX) // BS,
     ppochs=EPOCHS)
predIdxs = model.predict(testX, batch_size=BS)
 redIdxs = np.argmax(predIdxs, axis=1)
  rint(classification_report(testY.argmax(axis=1), predIdxs, target_names=lb.classes_))
```



### Trainer






```
# 모델 저장
print("[INFO] saving mask detector model...")
model.save("mask_detector.model", save_format="h5")

# 산설물과 정확도 띄우기
N = EPOCHS
plt.style.use("ggplot")
plt.figure()
plt.plot(np.arange(0, N), H.history["loss"], label="train_loss")
plt.plot(np.arange(0, N), H.history["val_loss"], label="val_loss")
plt.plot(np.arange(0, N), H.history["accuracy"], label="train_acc")
plt.plot(np.arange(0, N), H.history["val_accuracy"], label="val_acc")
plt.title("Training Loss and Accuracy")
plt.xlabel("Epoch #")
plt.ylabel("Loss/Accuracy")
plt.legend(loc="lower left")
plt.savefig("plot.png")
```


```
### Annual Control of the Control o
```




### Trainer





















발표

실행기 설명

## 그리고 DNN







### 발표 실행기 설명

### Visualizer

트레이너



실행기



```
ensorflow.keras.applications.mobilenet_v2 import preprocess_input
    tensorflow.keras.preprocessing.image import img_to_array
   n tensorflow.keras.models import load_model
   ort matplotlib.pyplot as plt
FPS = 30
 afetyhelmet_similarities = []
  f detect_and_predict_hat(frame, faceNet, hatNet);
   (h, w) = frame.shape[:2]
   detections = faceNet.forward()
           (startX, startY, endX, endY) = box.astype("int")
           (startX startY) = (max(0, startX), max(0, startY))
           face = frame[startY:endY, startX:endX]
           face = cv2.cvtColor(face, cv2.COLOR_BGR2RGB)
           face = img_to_array(face)
           face = preprocess_input(face)
           faces.append(face)
           locs.append((startX, startY, endX, endY))
```

```
faces = np.array(faces, dtype="float32")
       preds = hatNet.predict(faces, batch_size=32)
   return (locs, preds)
  ototxtPath = r"face_detector\deploy.prototxt"
 faceNet = cv2.dnn.readNet(prototxtPath, weightsPath)
hatNet = load_model("mask_detector.model")
vs = VideoStream(src=0).start()
    current_time = time.time() - prev_time
       prev_time = time.time()
    frame = imutils.resize(frame, width=1024)
    (locs, preds) = detect_and_predict_hat(frame, faceNet, hatNet)
       (startX, startY, endX, endY) = box
       (hat, withouthat) = pred
       cv2.putText(frame, text, (startX, startY - 60), cv2.FONT_HERSHEY_SIMPLEX, 0.5, (255, 255, 255), 2)
       label = "Please put on your Hardhat" if safetyhelmet_similarity < baseline else "PASS"
       cv2.putText(frame, label, (startX, startY - 10), cv2.FONT_HERSHEY_SIMPLEX, 0.45, color, 2)
       cv2.rectangle(frame, (startX, startY), (endX, endY), color, 2)
```







```
if key == ord("q"):
        break

# Case Similarity 평균값을 파일에 저장


with open("similarity.txt", "w") as file:
        for cs in safetyhelmet_similarities:
            file.write(f"{cs}\n")


# 파일에서 similarity 데이터 읽어오기

with open("similarity.txt", "r") as file:
            similarity_data = [float(line.strip()) for line in file]

# 그래프 생성 및 이미지로 저장
plt.plot(similarity_data)
plt.xlabel('Frame')
plt.ylabel('Safetyhelmet Similarity')
plt.title('Safetyhelmet Over Frames')
plt.savefig('sim.png')
plt.show()


cv2.destroyAllWindows()
vs.stop()
```



























결론

Conclusion

결론, 맺음말, 소감

와! 끝났다!

0

### 위기를 기회로!

Kaggle이 동작하지 않았기 때문에 재밌는 경험 추가 02

### 재밌었지만 아쉬웠다

결과가 성공적으로 출력되어 만족하나 분류가 정확하지 않을 때가 간혹 있었다 코드 추가로 결과값은 잡았으나 아쉬움 03

# 조금 더해볼까?

(여유 있을 때) 해당 코드에서 아쉬운 점을 보완해 제대로 된 결과를 내겠다

# Make Experience Great Again

질문 있을까요?

Q&A

# 질문 있을까요?







